## **CHEERICO**

## **SQUARE Acrylic Cupcake Stand**

Thank you for purchasing one of our acrylic products. Please follow the guide below to ensure your product is assembled correctly and avoid potential damage.

PLEASE NOTE: You must remove the manufacturers' protective cover before assembling this product. This covering is clear bubble and cling wrap on both sides of every acrylic component.

## ASSEMBLY GUIDE:

Parts: Acrylic discs, head screws, acrylic rods and acrylic feet.

- 1. Remove the manufacturer's protective cover from BOTH side of each acrylic component.
- 2. Take 4 metal head screws and place it on to a flat surface where the stand is to be constructed
- 3. Now screw the 4 acrylic rods onto the screw thread of the head screw making sure the acrylic disc is clamped firmly between two components.
- Т Head Screw DISC 1 -TΤ TΤ DISC 2 TT DISC 3 TTTTTΤ DISC 4 TTTTAcrylic Rods DISC 5 TTTTDISC 6 T DISC 7-TTTTFEET FEET
- 2. Begin by placing the feet to the underside of the bottom disc ensuring they are evenly spaced.
- 5. Carefully line up the hole(s) of the largest disk with 4 head screws ensuring the disc is resting securely on the acrylic feet.
- 6. Continue by placing the next largest disc on to the screw thread of rods and tighten each piece as you go.
- 7. The final rod is to be used as the supposed for the top tier and the stand is completed by adding the other screw cap into the top.

## CARE GUIDE:

- The stand is made from acrylic which will scratch if it is not looked after properly.
- To clean the product use warm water with a little washing-up liquid and soft cloth.
- Do not use any abrasive cleaning products as they will make the acrylic.
- Do not put the stand in a dishwater

If you have any questions, please contact us via contact@cupcakestand.com.au

